

AIRCRAFT PARKING/DOCKING CHART-ICAO

УЛААНБАТАР/Chinggis Khaan (ZMCK)

STAND NR	COORDINATES	ELEV	AIRCRAFT CLASSIFICATION BY CODE NUMBER AND LETTER	BEARING STRENGTH
1	47° 39' 02.89" N; 106° 49' 14.16" E	1369	4C	PCR 1010/RB/W/T
2	47° 39' 01.74" N; 106° 49' 15.33" E	1369	4D	
2R	47° 39' 01.59" N; 106° 49' 15.38" E	1370	4E	
3	47° 39' 01.29" N; 106° 49' 17.74" E	1369	4D	
4	47° 39' 02.00" N; 106° 49' 19.88" E	1369	4E	
6	47° 39' 02.12" N; 106° 49' 24.44" E	1370	4E	
6A	47° 39' 01.10" N; 106° 49' 28.05" E	1369	4C	
6B	47° 39' 01.43" N; 106° 49' 23.17" E	1369	4C	
7	47° 38' 59.77" N; 106° 49' 28.53" E	1369	4C	
8	47° 38' 59.43" N; 106° 49' 28.42" E	1369	4C	
9	47° 38' 59.00" N; 106° 49' 30.80" E	1369	4D	
21	47° 39' 03.99" N; 106° 49' 12.08" E	1370	4E	
22	47° 39' 04.18" N; 106° 49' 07.79" E			
23	47° 39' 03.07" N; 106° 49' 07.36" E			
24	47° 39' 01.96" N; 106° 49' 06.92" E	1370	3C	
25	47° 39' 04.82" N; 106° 49' 04.16" E			
26	47° 39' 03.71" N; 106° 49' 03.73" E			
27	47° 39' 02.60" N; 106° 49' 03.30" E			

Note: Aircraft stand 2R is used only for A330-300 and A330-200 types of aircraft.

Code letter	Wing span
C	24m up to but not including 36m
D	36m up to but not including 52m
E	52m up to but not including 65m